SPEEDSET GS

Let Speedset change the speed of your IIGS for you. This short machine language utility will set the speed to slow or fast, without the Control Panel.

If you use the Apple IIGS, you know that the new 65816 processor has brought a welcomed speed boost to much of your software. Unfortunately, not all the software can take advantage of this speed. Most of these programs are areade games.

Since I prefer to leave the default speed at fast, it must be rest whenever I play a game. However, I can never remember to do that until I see the graphic shapes soom across the screen. If the software disables interrupts, the only way to call up the Control Panel is to reboot the system. And since my preschooler also plays some of these games-shooler also plays some of these games showing down the processor automatically without changing the default.

Speedset is such a routine — in fact, it's two assembler subroutines, one to set the two assembler subroutines, one to set the speed to normal and the other reset it to the fact speed. Each routine is small and needs no input. To combine them into one subroutine would require making the routine more complex than it needs to be. Each subroutine sousmes that the IIGS is running in 6502 emulation; otherwise, native-mode software can set the seed on its own.

USING THE PROGRAM

Speedset is compatible with all Apple II operating systems; however, there should be no need to use it with ProDOS 16. It is also relocatable, and can be added to your collection of assembler routines. Speedset can be called from the HELLO program. Insertine the following command:

PRINT CHR\$(4); "BRUN SPEEDSET,

into any BASIC program not only loads the program but executes the subroutine SLOW to place the processor into the slower speed. The faster speed can be activated by calling the load address plus 17. Using the above example as a load address, the call would look like this.

CALL 768+17

The demonstration (Listing 1) shows how you can incorporate Speedset into a program and how different processor speeds affect an Applescoft program. Since there may be advantages to switching the speeds within a program, a possible enhancement would be to install Speedset as a ProDOS command. Also, Speedset can be called from other make some medifications based on your application.

ENTERING THE PROGRAM

I used the ORCA/M assembler because it is also compatible with the Apple Programmers Workshop (APP). If you say a APW, the 65816 ON at line 2 is not needed. Also, since APW generates Object Module Format (OMF), the utility Macbin must be run to convert the cutiput to a binary load file if Speedies is to be used under ProDOS 8 or DOS 3.3.

Type in the Applesoft demonstration program in Listing 1 and save it to disk with the command:

SAVE SPEEDSET.DEMO

If you have an ORCA/M or APW assembler, type in the source code from Listing 2 and assemble it, saving the object code as SPEEDSET. If you don't have no of those assemblers, type in the machine code from Listing 3 and save it to disk with the command:

BSAVE SPEEDSET,A\$300,L\$22

HOW THE PROGRAM WORKS

Speodes's mechanics are single. First, the program must sowich between emulation mode and native mode by setting or clearing a pain access to the Emulation bit, and the Standardor bit is sown as a pain access to the Emulation bit, we say that the program first clears the Carry bit with a CLC and then transfers the bit to the Emulation bit, we ensure that the Emulation bit with the XCEI command. By clearing the Emulation bit, we ensure that the processor will be running in native mode. Native mode is necessary to guarantee access. Native mode is necessary to guarantee access to the program of the pro

The next step is to make sure the length of the accumulator is 8 bits. This is done by issuing a SEP with a bit string of (0010000.0). S20, setting the M bit in the status register. The reason for this becomes obvious when we manipulate the high bit of the byte at SEO-CO36 (i.e., location SCO36 of bank SEO-CO37.

The LDA < SEOCO37.

The LDA < SEOCO36 fores long address-

ing to ensure access to the byte in the correct bank. To set normal speed, set the high bit to zero; conversely, a high bit set to 1 sets the speed to fast. Next, the byte is saved back to the configuration register. The last thing to do before returning to the

caller is to return to emulation mode. This is accomplished by setting the Carry bit and transferring it to the Emulation bit.

Listings for Speed Set GS		slew	stert		
LISTING 1: SPEEDSET.DEMO		1 :	switch from 6502 cmulation to native mode		
37 20 39 4E 24 15 17	18 RUM - SPEEDET DEMO 20 REM - SPEEDET DEMO 30 REM - SPEEDET DEMO 30 REM - SPEEDET DEMO 40 REM - GOVERNMENT (C) 1888 - 80 REM - RECORDENIE, 1802 - 70 REM 70 REM 90 ROME : PRINT CHRS (4) BRUN SPEEDSET, A768	,	cic sce sep #528 longe off ids >5-00-036 and #577 518 >5-00-036 return to 6502 e sec sce	clear carry flag exchange carry with E bit (clear E bit) set 8 bit accumulator tell assembler about it get the configuration register in page E0 erase high bit nave byte back in configuration register	
E	100 IF NOT S THEN VTAB 23: HTAB 10: PRINT "S peed is set to slow": CALL 768	-	rts		
93	110 IF S THEN VTAB 23: HTAB 10: PRINT "Speed	:	switch from 6502 emulation to native made		
	120 a set to fast: CALL 768 + 17 120 a set to fast: CALL 768 + 17 120 NEXT 120 FOR 1 = 170 19; FOR 1 = 0 To 180 NEXT 170 FOR 1 = 39 TO 1 STEP - 1: FOR 1 = 8 TO 18 170 FOR 1 = 39 TO 1 STEP - 1: FOR 1 = 8 TO 18 170 FOR 1 = 39 TO 1 STEP - 1: FOR 1 = 8 TO 18 170 FOR 1 = 39 TO 1 STEP - 1: FOR 1 = 8 TO 18 170 FOR 1 = 39 TO 1 STEP - 1: FOR 1 = 8 TO 18 170 FOR 1 = 39 TO 1 STEP - 1: FOR 1 = 8 TO 18 170 FOR 1 = 30 TO 1 STEP - 1: FOR 1 = 8 TO 18 170 FOR 1 = 10 STEP - 1: FOR 1 = 10 STEP - 1 170 FOR 1 = 10 STEP - 1: FOR 1 = 10 STEP - 1 170 FOR 1 = 10 STEP - 1 170	fast	cic xce sep #528 lengs off ids >5e0c035 ore #580 sts >5e0c036 return to 6502 e sec rts end	clar cary fig. exchange carry with E bit (clear E bit) ext & bit occumient ext & bit occumient ext & bit occumient ext & bit occumient get the configuration register in page 68 ext high bit mark bits become configuration register mixision made ext carry fig. exchange carry with E bit (set E bit)	
LISTING 2: SPEED.SRC keep speedset 65916 on		LISTING 3: SPEEDSET Start: 2000 Length: 22			
SPEEDSET.SEC SPEEDSET.SEC PF. Edward D. Osiccioli, Jr Goypright (c) 1988 Brookfolk, 1984		54 2000:18 FB E2 20 AF 35 C0 E0 2C 2008:29 7F 8F 36 C0 E0 38 FB 04 201:06 18 FB E2 20 AF 36 C0 A1 2018:E0 09 80 SF 36 C0 E0 38 36 2020:F6 60			
ORCA/M Macro Assembler			TOTAL: ØDCA END OF LISTING 3		