

With reference to Sun Systems Remarketing (which used to be Sun Data), they may be contacted at P.O. Box 4059, Logan, Utah 84321. If you are into telecommunication, have a modem and are really eager for information, they have a BBS where you can download the latest price lists, find out about other users etc. For more information, call their service line (801) 753-2899. They have a monthly publication "Sun Times" from which the following excerpted material was taken to give you an example of the type of articles included:

"Because device drivers take up so much space on a disk it is not reasonable to have all possible drivers installed. So, in some cases you may need to either create a two-stage (two-disk) boot or delete unnecessary drivers. A good rule is to put only the drivers actually needed on each boot diskette. Nevertheless, in order to create a two-stage Utility Boot, you simply need to divide the files onto two separate diskettes. First format two diskettes naming one SYS.UTIL1 and the other SYS.UTIL2. Then copy from your backup copy of the Systems Utilities Program the following files: (SOS.KERNEL), (SOS.INTERP) and (SOS.DRIVER) to the diskette you named SYS.UTIL1. Next, copy the files of (SYSTEM.MISCINFO), (SYSTEM.PASCAL) and (SYSTEM.STARTUP) to the diskette you named SYS.UTIL2.

In order to use these put the first disk in the built-in drive and enter CONTROL/RESET to boot the system. After that portion of the operating system loads it will ask you to "Put system Disk in Built-in Drive". After you insert your second diskette in the drive enter RETURN and the Utilities Main Menu will come to the screen. You'll now have plenty of room for even the largest of driver files."