

Q3. Can you use an ImageWriter with the A/// and do you need a new driver?

A3. Yes. To use the ImageWriter one needs a standard serial cable (like you would use your modem with), a "Modem eliminator" and any serial driver. The serial driver must be configured to match the baud rate of your printer (the Imagewriter is normally set at 9600 baud). The modem eliminator came from Apple with the earlier ///s, but not lately. Another solution is to build a cable that incorporates both the serial cable and the Modem Eliminator. An article on how to do this was included in the February issue of this Newsletter.